


Enabling Califone 3066-USB

Enabling headsets requires a little time and a lot of patience. Older machines tend to not recognize and adjust the mic volumes accordingly. The good news is that installation is a software (device driver) process so once the headset is enabled on a computer, any user will have access to using the headset.

In order to enable the headset and adjust volume, please do the following:

1. Plug in the USB to a port on the computer. If the computer has never had one of these devices connected, it will install device driver software. This installation may take up to 5 minutes on older machines. Please be patient.
2. Click on the volume control in the lower right hand corner of your desktop screen. Click on “mixer”.



3. When the window opens, click on “system sounds”.

3. A new window will open. Choose the “recording” tab. You should see the enabled devices for this recording function.

If you don't, right click to open devices and select “Show Disabled Devices”.


4. Select the USB microphone and click “configure”.



5. In the next window, choose “Set up microphone”.




6. If not already selected choose “headset microphone”. Click “next”.





7. When the window opens, follow the instructions for setting up the volume. and click next.

8. Read the phrase clearly until the computer allows you to click next and move on to the next step.




9. The pop up window should look like this. Success! →



You'll notice that this window has not gone away. Click "properties"

This will allow you to change the icon to match the Headset. You can even change the name to "USB Headset".



Click "okay", close any leftover windows, and you are ready to go!